

SigenStor Home Installation Guide

Single-phase System A1

Version: 01
Release date: 2023-07-31




⚠ Caution

- Trained or experienced electrical personnel are required to operate the equipment.
- Operators should be familiar with national/regional laws, regulations and standards, the structure and working principle of relevant systems.
- Please read carefully the operating requirements and precautions in this document and Important Notice before operating. Failure to do so may result in damage to the equipment that is not covered by the warranty.


1 Introduction to Single-phase System

1.1 Introduction to Networking

Backup networking



Non-backup networking



Tips

It is recommended to use FE and WLAN for communication with inverter. Sigen CommMod users must top up their own 4G data plan after a period of 2 years.


S/N	Equipment/component	Model/version	Function specification
A	PV module	-	-
B	SigenStor EC	SigenStor EC 3.0/3.6/4.0/4.6/5.0/6.0 SP	Inverter; it can be used in photovoltaic energy storage scenarios and needs to be used together with PV modules and SigenStor BAT.
	SigenStor AC	SigenStor AC 3.0/3.6/4.0/4.6/5.0/6.0 SP	Inverter; it can be used in pure storage scenarios and needs to be used with SigenStor BAT.
	Sigen Hybrid	Sigen Hybrid 3.0/3.6/4.0/4.6/5.0/6.0 SP	Inverter; it can be used in conjunction with PV modules for pure PV applications or in combination with PV modules and SigenStor BAT for photovoltaic storage systems after the purchase and activation of a license.
C	SigenStor BAT	SigenStor BAT 5.0/8.0	Battery pack; it can store electric energy.
D	Diesel generator	-	As a backup energy source for long-term off-grid applications, it can work in tandem with the Gateway to provide a smooth transition between PV, storage and diesel generator.
E	Gateway	Sigen Gateway HomeMax SP	It's applicable for PV storage and pure storage applications to facilitate data acquisition and monitoring, off-grid backup power switching, diesel generator control, energy management; it must be used with SigenStor BAT. Gateway is a must-have for backup networking; for partial backup power and zero-power grid connection control networking, the Gateway and power sensor must be arranged.
F	Electric equipment	-	In the backup networking, F1 is the electric equipment for backup; F2 is non-backup the electric equipment; G1 is the backup Distribution panel; G2 is the non-backup Distribution panel.
G	Distribution panel	-	The rated voltage of the AC switch connected to each inverter should be ≥ 240 V AC and the rated current is recommended: <ul style="list-style-type: none"> SigenStor EC/SigenStor AC/Sigen Hybrid (3.0-4.0) SP: The rated current is 25 A SigenStor EC/SigenStor AC/Sigen Hybrid (4.6-6.0) SP: The rated current is 40 A
H	Power sensor	Sigen Sensor SP-DH (SDM230 MODBUS) Sigen Sensor SP-CT-DH (SDM120 CTM)	Data acquisition for grid connection points enables zero-power grid connection. No power sensor is needed for home-wide backup networking.
I	Power grid	-	-
J	App	mySigen	Android 6.0 or later iOS 12.0 onwards
K	Router	-	To be used for FE/WLAN communication.
L	Antenna	-	To be used for WLAN communication.
M	Communication module	Sigen CommMod	To be used for 4G communication.

Tips

For further information on the installation and wiring of Gateway, refer to the corresponding documentation.


1.2 Equipment Appearance and Dimensions

Inverter and battery pack



1.3 Port Descriptions

SigenStor EC/ SigenStor AC/Sigen Hybrid Left View



S/N	Name	Marking
1	DC switch	DC SWITCH
2	Decorative cover light strip connector	LED
3	Antenna interface	ANT
4	Cable interface	RJ45 1/ RJ45 2
5	AC output interface	AC
6	Ground screw	-
7	Communication interface	COM
8	Sigen CommMod interface	4G
9	DC input interface	PV1+/PV2+/ PV1-/PV2-
10	Switch button	ON/OFF

2 Pre-installation Check

- According to the packing list, check whether the components are complete and in good appearance. If any abnormality occurs, contact your sales agent in time.
- Check personal protective equipment and installation tools to ensure that they are complete; if not, please make them up.
- Check the customer-provided cable to ensure that the quantity and specifications are correct; if not, prepare again.

Protective equipment



Safety hat



Goggles



Dust mask



Protective gloves



Insulating gloves



Insulated shoes

Installation tool



Power drill



Vacuum cleaner



Wire cutter



Hydraulic pliers



Crimping pliers



Wire stripper



Scissors




Cable tie



Heat shrinkable sleeve



Heat gun



Insulation screwdriver set sleeve



Insulation sleeve set



Crane
(used when SigenStor
BAT \geq 3 units)



Stainless steel covered
plastic steel rope
(bearing: \geq 250 kg
Diameter: 3 mm)



Open-end wrench
(model: H4TW0001
Manufacturer:
Amphenol)



Crimping pliers
(model: H4TC0003
Manufacturer:
Amphenol)



Lock (Lock bar
diameter \leq 5 mm)



Torque socket
wrench



Marker



Rubber mallet

Installer-provided cable

S/N	Cable name		Recommended specifications
1	Protective ground cable of inverter housing		Outdoor single-conductor copper cable Cross-sectional area of core conductor: 4-6 mm ² Outer diameter: 4-8 mm
2	AC cable	The inverter connected to the distribution panel	Outdoor three-core copper cable (L, N, PE) Cross-sectional area of core conductor: 4-6 mm ² Outer diameter: 13-21 mm
3	RS485 signal cable	The inverter connected to the power sensor	Outdoor shielded twisted pair Cross-sectional area of core conductor: 0.5-0.75 mm ² (multi-core flexible conductor; Tubular terminal needed) 0.5-1 mm ² (single-strand hard conductor; no tubular terminal needed) Outer diameter: 4.5-6.5 mm
4	RJ45 network cable	The inverter connected to the router	Outdoor eight-conductor shielded twin-twisted pair cable Cross-sectional area of core conductor: 0.13-0.2 mm ² Outer diameter: 4-7.5 mm
5	DC input cable of inverter (Ignore this cable in case of SigenStor AC inverters)		Outdoor photovoltaic cable Cross-sectional area of core conductor: 4-6 mm ² Outer diameter: 5.5-9 mm

Tips

Recommended specifications for cables connecting power sensors to Distribution panel and to the grid, as well as step-by-step instructions for wiring, can be found in the accompanying documentation for each respective model.

3 Equipment Installation

Installation environment


- Do not install the equipment in smoky, flammable, explosive, or corrosive environments.
- Do not install the equipment outdoors in areas prone to salt damage area, which are located less than 500 meters from the coastline or affected by sea wind.
- Do not install the equipment in environments exposed to direct sunlight, rain, standing water, snow accumulation, sand, and dust. It is recommended to install in a sheltered location. If the area is susceptible to natural disasters such as floods, landslides, earthquakes, or typhoons, take preventive measures during equipment installation.
- Do not install the equipment in environments with electromagnetic interference.
- Ensure that the temperature and humidity of the installation environment comply with the equipment's requirements.

Installation position

- Do not tilt or overturn the equipment to ensure that it is installed horizontally.
- Do not install the equipment in a place easily touched by children.
- Do not install the equipment in places with fire or damp (including but not limited to kitchen, tea room, toilet, shower room, laundry room, etc.).
- Please keep away from the daily work and living places (including but not limited to living room, bedroom, studio, lounge, study, etc.)
- Do not install the equipment in areas with difficult access (including but not limited to attic, basement, etc.).
- Do not install the equipment in mobile scenarios such as RVS, cruise ships, and trains.
- You are advised to install the equipment in a position that is easy to operate, maintain, and view indicator status.
- When installing the equipment in the garage, do not install the equipment in the position where the vehicle passes through to avoid collision.

Mounting surface

- Do not install the equipment on a flammable carrier.
- The installation carrier must meet load-bearing requirements. Solid brick-concrete structure, concrete walls, and ground are recommended.
- The surface of the installation carrier must be smooth and the installation area must meet the installation space requirements.
- No water or electricity is routed inside the carrier to prevent drilling hazards during equipment installation.



SSA1SF0002


4 Installation of inverter and battery pack

Tips

- At least two people are required to install the equipment.
- Up to six SigenStor BATs are supported for floor installation and up to two for wall installation.
- When installing three or more SigenStor BATs on the floor, use the crane tool.
- Multiple SigenStor BATs can be installed onsite based on the actual configuration.
- If there is water on the floor, install it on the wall.
- The equipment is heavy, do not slip off when handling the equipment to avoid the equipment falling and injuring the operator.
- SigenStor BAT is forbidden to be used after falling, please buy a new one.

4.1 Floor Installation


- 1 If the horizontal bubble is not centered, use a leveling gasket to level it.



SSA1IN00004

Wall fastener	L
	25 mm to 43 mm
	52 mm to 70 mm

- 2 Follow the steps on the underlined template. PACK is the punch point for SigenStor BAT, and INV is the punch point for SigenStor EC, SigenStor AC, Sigen Hybrid.





SSA1IN00005

Tips


After installing the expansion bolt on the wall, remove the nut and store it properly for later use.

- 3** Before installing the handle, ensure that the screws on the SigenStor BAT are secured with a tightening torque of 4.5 N·m.



SSA1IN00006


- 4** SigenStor BAT is kept horizontally and mounted vertically downwards.



SSA1IN00007

- 5** For details about how to place the second SigenStor BATs, see Steps **3** **4**.

- 6** (Optional) If three or more SigenStor BATs are to be installed, use a crane tool. For details about the hoisting rope binding scheme, see the figure.



SSA1IN00008

Tips

During lifting operations, the area where the sling comes in contact with the equipment should be wrapped with a protective layer to avoid damage to the equipment.

7 Arrange SigenStor EC, SigenStor AC or Sigen Hybrid.

SigenStor EC or SigenStor AC


For details, see Step **4** .

Sigen Hybrid



Remove the IP protection cover at the bottom, install the chuck screws of the decorative covers, and arrange them as described in Step **4** .

Tips


The chuck screws are packed in the extension package.



SHA11N00001





SHA11N00002





SSA11N0009

9



SSA1IN0010


10




SSA1IN0044

4.2 Wall Installation



1



2



3



4 For details about how to place the SigenStor BAT, see Steps 3 4 of 4.1 Floor installation.

5 For details about how to fix the equipment, see Steps 8 9 10 of 4.1 Floor installation.

5 Cable Connection and Component Installation

Warning

Before connecting cables, ensure that DC SWITCH is in the OFF state, and the front switch of the AC line is off.


Tips

- The cable colors in the figure are used only to distinguish different lines. The cable colors are based on actual conditions.
- Bind the power cable separately from the signal cable.

5.1 Recommended Cabling installation

Scheme I


-  AC output cable
-  RS485 signal cable
-  Protective ground cable
-  RJ45 cable
-  DC input cable
-  DC input cable




Tips

- There are three routing schemes, Select them based on the actual situation.
- If pipe routing is used onsite, the recommended pipe diameter is at least 67 mm.

Scheme II





Scheme III



5.2 Protective Ground Cable of Inverter Housing

Tips


The protective ground wire should be grounded in close proximity.






5.3 AC Output Cable of Inverter

Tips

One end of the AC cable is connected to the inverter, and the other end is connected to Distribution panel.





SSA1IN0019


5.4 RS485 Signal Cable

Tips

If a power sensor is used, one end of the RS485 signal cable is connected to the inverter while the other end to the power sensor.

5.4.1 Introduction to Correspondence

COM terminal of the inverter




Tips


The appearance and specific wiring of the power sensor can be found in the instruction manual delivered with the case.

Description	Interface definition	COM terminal of the inverter	Sigen Sensor SP-DH (SDM230 MODBUS)	Sigen Sensor SP-CT-DH (SDM120 CTM)
(Reserved) DO1, connected to third party intelligent electric equipment, such as switch control and heat pump	Dry contact 1 - Common	1	-	-
	Dry contact 1 - NO	2	-	-
(Reserved) DO2, connected to third party intelligent electric equipment, such as switch control and heat pump	Dry contact 2 - Common	3	-	-
	Dry contact 2 - NO	4	-	-
(Reserved) For power scheduling, such as DRM and Ripple control	DI1, digital input 1	5	-	-
	DI2, digital input 2	6	-	-
	DI3, digital input 3	7	-	-
	DI4, digital input 4	8	-	-
	DI5, digital input 5	9	-	-
	Signal GND	10	-	-
COM port used to access the power sensor	PE signal shielding ground	12	-	-
	RS485 signal 2_B-	13	6	9
	RS485 signal 2_A+	14	5	10
(Reserved) Standby RS485 port	PE signal shielding ground	11	-	-
	RS485 signal 1_A+	15	-	-
	RS485 signal 1_B-	16	-	-

5.4.2 Connection on the Inverter Side



SSA1IN00021




SSA1IN00022



5.5 RJ45 Cable

Tips

RJ45 cables are EIA/TIA 568B standard cable.




- White orange
- Orange
- White green
- Blue
- White blue
- Green
- White brown
- Brown





5.6 Sigen CommMod Installation

Tips

Sigen CommMod is required for 4G communication.




S/N	Indicator	Description
1	Power indicator	-
2	Network state indicator	<ul style="list-style-type: none"> Slow flashing (200 ms on/1800 ms off): The network is being connected Slow flashing (1800 ms on/200 ms off): Standby Quick flashing (125 ms on/125 ms off): Data is being transferred



5.7 WLAN antenna stick Installation

Tips

WLAN communication requires the installation of WLAN antenna stick.




SHA1IN00009


5.8 DC input cable of inverter

Tips

The DC cable is connected to the inverter from the PV string. Ignore this section in case of SigenStor AC inverter.



SSA1IN00024





6 Post-installation Check

S/N	Check Item
1	The equipment has been securely installed.
2	The cable fastening screws or terminals are properly installed.
3	There are no sharp spikes or acute angles at the cut point of the cable tie.
4	DC SWICH is in the OFF state.
5	Ports that are not in use have waterproof covers or plugs installed.
6	There is no construction left inside or outside the equipment.

⚠ Caution


- If the voltage is negative, the polarity is incorrect. Rectify the fault in time.
- If you have only one DC input, connect it to PV1.



SSA1IN0038

After confirmation, install the SigenStor BAT and SigenStor EC /SigenStor AC/Sigen Hybrid decorative covers.

7 Installation of the Decorative Cover




⚠ Caution

- The end waterproofing plug for the light strip in step 1 is at the lower end of the decorative cover on the left side of the inverter, please remove it for spare.
- If the equipment is not equipped with a decorative cover light strip, ignore Steps 1 3 5 6 in the figure.

8 Equipment Power-On

1. Turn on the front switch of the equipment.
2. Rotate DC SWITCH to ON. (This step is not necessary for SigenStor AC)
3. Observe the indicators on the front side of the inverter to learn about the equipment status.




SSA1IN00027

Indicator	Color	State	Description
	White	Always on	The DC side is connected but not running.
	Green	Always on	The DC side is running.
	Grey	-	The DC side is not connected.
	Orange	Flash	The DC side is faulty.
	Red	Always on	The inverter is faulty.
	White	Always on	The AC side is connected but not running.
	Green	Always on	Grid-connected operation.
	Blue	Always on	Off-grid operation.
	Grey	-	The AC side is not connected.
	Blue	Flash	Off-grid overload operation.
	Orange	Flash	The AC side is faulty.
	Red	Always on	The inverter is faulty.

Indicator	Color	State	Description
	White	Always on	All SigenStor BATs are connected but not running.
	Green	Flash	SigenStor BAT is charging.
	Blue	Flash	SigenStor BAT is discharging.
	Grey	-	All SigenStor BATs lie dormant.
	Red	Flash	Some SigenStor BATs are faulty.
	Red	Always on	All SigenStor BATs are faulty.
	Grey	-	The management system is not connected.
	Green	Flash	Connected to local APP.
	Green	Always on	Connected to the management system using an FE or WLAN.
	Blue	Always on	Connected to the management system over 4G.

After powering on the equipment, install the remaining decorative covers.




SSA1IN00043


9 Download and create new system for mySigen App

- 1 Please enter the "Partner" → "Register Now" at the Company's official website (<https://www.sigenenergy.com>), and complete the account registration based on facts.
- 2 Download the mySigen App and create new system for the device.



Tips

Do not use only WLAN communication for creating the new system. To use the WLAN, install Sigen CommMod or RJ45 network cables at the same time. Otherwise, it would be impossible to create the new system.






or





SSA1IN00031



Scan the SN code label on the accompanying box material. If the SN is lost, scan the SN on the side of the inverter or SigenStor BAT.

Locate the address manually and complete the Total Panel Capacity and Owner Details

If an upgrade is required, perform the upgrade



You can manually set and modify some function parameters of the power station.

3 The installer should notify the owner of activating the account within 24 hours.

Sigenergy Technology Co., Ltd.



Website	LinkedIn	YouTube
---------	----------	---------

www.sigenergy.com



Copyright © Sigenergy Technology Co., Ltd. 2023. All rights reserved.

Description in this document may contain predictive statements regarding financial and operating results, product portfolio, new technology, configurations and features of product. Several factors could cause difference between actual results and those expressed or implied in the predictive statements. Therefore, description in this document is provided for reference purpose only and constitutes neither an offer nor an acceptance. Sigenergy Technology Co., Ltd. may change the information at any time without notice.